


INSTRUCTION MANUAL LEG PRESS OPTION OF GX GYM (BCG-GX)



QUESTION?

As a quality home gym supplier we are committed to your complete satisfaction. If you have questions, or find missing or damaged parts, we will guarantee your complete satisfaction through our authorized dealer service centers or our home office customer service department. Please call your local dealer for assistance or BodyCraft at 800-990-5556 (9:00 AM - 5:00 PM). Our trained technicians will provide immediate assistance to you, free of charge.

Bodycraft is a division of Recreation Supply Inc. 7699 Green Meadows Drive Lewis Center, OH 43035

MZ6882

BEFORE YOU BEGIN

Congratulations and thank you for selecting the **BODYCRAFT GX GYM LEG PRESS** strength training system. The **BODYCRAFT GX GYM LEG PRESS** offers an impressive array of strength training exercises to develop every major muscle group of the body.


Whether your goal is cardiovascular fitness, a shapely, toned body or dramatic muscle size and strength, the **BODYCRAFT GX GYM LEG PRESS** will help you achieve the specific results you want.

For your safety and benefit, read this manual and the accompanying literature before using the BODYCRAFT GX GYM LEG PRESS. Keep this manual for future reference. If you have additional questions, please call your local BODYCRAFT dealer or our customer service department at 800-990-5556 Monday through Friday, 9 a.m. until 5 p.m. Eastern Time.

IMPORTANT SAFETY NOTES

There is a risk assumed by individuals who use this type of equipment. Before beginning this or any other exercise program consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. Recreation Supply, Inc. assumes no responsibility for personal injury or property damage sustained by or through use of this product.

- 1. This product must be assembled on a flat, level surface to assure its proper function.
- 2. Clean pads and frame on a regular basis. We recommend warm, soapy water. Do not use harsh or abrasive chemicals.
- 3. Inspect and tighten all parts before every use. Replace any worn parts immediately. Failure to do so may result in serious injury.
- 4. Keep children away from the **BODYCRAFT GX GYM LEG PRESS** at all times.
- 5. Keep your hands away from cables and pulleys during operation. Keep your hands away from moving parts other than the designated handles.
- 6. Make certain all cables are seated within the pulleys before every use.
- 7. Exercise with care to avoid injury.
- 8. If unsure about the proper use of the **BODYCRAFT GX GYM LEG PRESS** strength training system call your local **BODYCRAFT** dealer or our customer service department at 800-990-5556.




PARTS LIST	
NO. DESCRIPTION QTY.	
201 BASE STABILIZER	
202 MAIN FRAME	1
203 LEG PRESS SUPPORT	
204 SEAT HANDLE	
205 BACK PAD ADJUSTER 206 FOOT PLATE	
206 FOOT PLATE 207 RUBBER STOPPER	
$208 \phi 25 \text{mm} \text{AXLE}$	
$209 \phi 3/4"$ AXLE	1 202 203
210 COLLAR	2 203
211 1-1/4" X 360mm HAND GRIP	2
(pre-assembled)	
212 NON SLIP 213 BACK PAD	
213 BACK FAD 214 SEAT PAD	
215 114mm PULLEY	1
216 90mm PULLEY	
217 LEG PRESS CABLE	
218 LOCKING SPRING KNOB	1 207 208 209 210 211 ⁽²¹²⁾
219 50 X 75mm RECT. PLUG	
220 45mm SQ. PLUG	
221 BEARING 222 LEG PRESS STOPPER	
222 LEG PRESS STOFFER 223 LEG PRESS BUSHING	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
224 1/2" X 4-1/4" HEX BOLT	
225 1/2" X 3-1/4" HEX BOLT	2 217
226 1/2" X 1" HEX THREADED BOLT	
227 3/8" X 4" HEX BOLT	
228 3/8" X 3-1/8" HEX BOLT	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
229 3/8" X 3" HEX BOLT 230 3/8" X 1-3/4" HEX BOLT	1 210 219 220 221 222 223 2
230 3/8 X 1-3/4 HEX BOLT 231 3/8" X 2-3/4" HEX THREADED BOLT	
232 3/8" X 1" HEX THREADED BOLT	2 224 229 234 239
233 3/8" X 5/8" SET SCREW	1
(pre-assembled)	
234 5/16" X 1-1/4" HEX THREADED BOLT	2
235 1/2" WASHER	
236 3/8" WASHER	12 226 231 236 241
237 1/2" NYLON NUT 238 3/8" NYLON NUT	
238 5/8 INTLON NOT 239 5/16" NUT (pre-assembled)	2 227 232 237 242
240 SEAT PAD SUPPORT STOPPER	
241 CAP FOR NUT	4 228 233 238 243
242 3/8" X 3-1/2" HEX BOLT	1
243 3/4" BUSHING	2
0 1/4 1/2 3/4 1" 1/4 1/2 3/4 2" 1/4 1/2	2 3/4 3" 1/4 1/2 3/4 4" 1/4 1/2 3/4 5" 1/4 1/2 3/4 6"
(inch)	

STEP 1 ASSEMBLE BASE FRAME

To ease assembly , Do Not tighten any bolts until instructed.

1. Attach the Base Stabilizer (201) to the Base Frame (1), using two 1/2" X 3-1/4" Hex Bolt (225), three 1/2" Washers (235) and one 1/2" Nylon Nut (237).



STEP 2 ASSEMBLE MAIN FRAME

- 1. Attach the Main Frame (202) to The Base Stabilizer (201), using two 1/2" X 4-1/4" Hex Bolts (224), four 1/2" Washers (235) and two 1/2" Nylon Nuts (237).
- Insert the 25mm Axle (208) into the Leg Press Support (203), then attach to the Main Frame (202) using two Collars (210) {inside the brackets on the Main Frame (202)}, two 1/2" X 1" Hex Threaded Bolts (228), and two 1/2" Washers (235). Tighten the bolts and then cap with two End Caps (241).
- 3. Insert the 3/4" Axle (209) into the top hole in the Leg Press Support (203), then attach the Foot Plate (206) using two 1/2" X 1" Hex Threaded Bolts (226), and two 1/2" Washers (235). Tighten the bolts and then cap with two End Caps (241).
- 4. Attach Seat Handle (204) to the Main Frame (202), using two 3/8" X 3-1/8" Hex Bolts (228), four 3/8" Washers (236) and two 3/8" Nuts (238).
- 5. Attach Seat Pad (214) to the Main Frame (202), using (216) two 3/8" X 2-3/4" Hex Threaded Bolts (231) and two 3/8" Washers (236). 238 6. Attach Back Pad (213) into the Back Pad Adjuster (205), (224 using two 3/8" X 1" Hex Threaded Bolts (232) and (235) two 3/8" Washers (236). Then slide the Back Pad (230)-Adjuster (205) to the Main Frame (202) and lock (230) at your desired position using the Spring Knob 201(224) (218). (232)235 206 235 (236)241 (205)(213)(226 (241 (232)(236) Œ (214)(218) (202)203 216 (236) 242 (236) (229 (235 (236) (223)(235)237 (227)(236) (228)

(235)

231

236

(223)

236

(236

238

(204)

(241)

(210)

(210

(208)

(238)

(23Š


(226

(226)

STEP 3 ASSEMBLE LEG PRESS CABLE

Assemble cables and pulleys simultaneously.

- Locate the Floating Pulley Block (21) assembled to the base unit of the GX. Unscrew the Floating Pulley Block (21). Screw the Rubber Stopper (207) into the Top Frame (2) in place of the Floating Pulley Block (21). Flip the Floating Pulley Block (21) over (you will need to remove the pulley when doing this) so that the flat end of Floating Pulley Block (21) is resting against the Rubber Stopper (207) as shown in Fig. 1.
- 2. Screw the threaded end of the Leg Press Cable (217) about half way into the threaded receptacle in the Floating Pulley Block (21). This is an adjustment area where the cable can be tightened or loosened. Be certain to always have at least one third of the threaded end of the cable screwed into the Floating Pulley Block (21). Also be certain to tighten the locking nut securely to prevent the cable from unscrewing.
- 3. Route the flat end of the cable down and under the vertical pulley (216) mounted to the Base Stabilizer (201) using one 3/8" X 1-3/4" Hex Bolt (230) and one 3/8" Nylon Nut (238) as shown in Fig. 2.
- 4. Continue routing the cable over to the horizontal Pulley (216) mounted to the Base Stabilizer (201) using one 3/8" X 1-3/4" Hex Bolt (230) as shown in Fig. 3.
- 5. Route the cable under a pulley mounted under the seat using two Leg Press Bushings (223), one 3/8" X 3" Hex Bolt (229), two 3/8" Washers (236), and one 3/8" Nylon Nut (238) as shown in Fig. 4.
- Continue routing over top of a pulley mounted in the end of the Leg Press Support (203) using two Leg Press Bushings (223), one 3/8" X 3" Hex Bolt (229), two 3/8" Washers (236), and one 3/8" Nylon Nut (238) as shown in Fig. 5.
- 7. Attach the flat end of the cable to the base of the Leg Press Support (203) using one 3/8" X 4" Hex Bolt (227) and one 3/8" Nylon Nut (238).



Assembly is complete! Please take the following steps before using the gym:

- 1. Make certain all bolts are tightened securely.
- 2. Make certain all cables are seated into all pulley grooves. A cable rubbing-against steel will peel the nylon coating, voiding warranty and resulting in a need for replacement.
- 3. Pre-stretch the cables. Pull on the cables with great force, helping remove any links and providing any initial cable stretch.
- 4. Be aware the cables can loosen and slightly stretch upon initial use.
- 5. For better performance, apply a household lubricant (such as silicone) to any adjustable areas.
- 6. Enjoy many years of a Fit Lifestyle.

Thank you for purchasing the BodyCraft GX GYM LEG PRESS. If You have any questions, please call your local BodyCraft dealer or call our customer service department at 800-990-5556