

WORKOUT STATION SETUP

CHOOSE THE BEST WAY FOR YOU

START WITH THE SENSOR

Install the Dual Sensor on your Indoor Cycle. See how to install the sensors below: [Dual Pro Sensor Installation](#)
[Dual Sensor Installation](#)



OPTION 1 – TABLET/PHONE

Using our Tablet/Phone Holder you can attach any tablet or phone to our bikes. You can now interact with the app directly from the bike while you ride as it is directly in front of you. Note: The sensor connects to each app when the app is being used. Do not try to pair the sensor directly with the phone/ tablet.


[Download Peloton](#)  [Download Zwift](#) 



OPTION 2 – HDMI

After connecting the Dual sensor to the bike and connecting it to your phone or tablet you can use an HDMI connector to expand your viewing capabilities. Using the HDMI connector you can now view your app on a Projector or a TV.

[Buy Android HDMI Connector](#)
[Buy Apple HDMI Connector](#)



OPTION 3 – CASTING / APPLE TV / CHROME CAST

Smart TVs have the ability to cast directly from the app on your phone or tablet to the TV itself through bluetooth and wifi. This is basically broadcasting your app over the air to your TV. Most Smart TVs use a casting app to do so. You can also use Apple TV or Chrome Cast. Apple TV has Zwift as an application you can download. You can directly connect the Dual Sensor to your Apple TV and interact with the app that way.

